ASSEMBLY

ATTACHING HOSE

See Figure 3.

■ Make sure the air compressor is off and unplugged.

Set up instructions:

1. Compressor is assembled at factory and ready for use. Check all components to ensure secure assembly, ie., rubber feet, wheels, handle, quick connects, gages, safety valve, air filter, drain valve, etc.
2. Apply thread tape to threaded connections of hose, attach quick coupler to hose with a wrench (wrench is not provided).
3. Apply thread tape to threaded connections of male plug, attach male plug to hose with a wrench (wrench is not provided).

■ Rotate pressure regulator knob fully counterclockwise.

■ Insert hose adapter end of air hose into female coupler end in air compressor.



Figure 3